




Parts List for EBC Beam Clamp



- **SEE NOTES BELOW WHEN ORDERING PARTS**

Part No.	Part Name	Quantity
EBC-P1	Clamp Assembly	1
EBC-P2	Spindle	1
EBC-P3	Spring Pin	1
EBC-P4	Handle Assembly	1
EBC-P5	Locked Screw	1
EBC-P6	Washer	1

- **When ordering parts, use the series prefix, capacity, and part number i.e. *EBC-1-P1* would be used when ordering the clamp assembly for a 1 ton beam clamp**

Elephant Lifting Products
 2718 South Ruby Street, Suite B
 Gonzales, LA 70737 USA
 Phone: 225-644-6113 Fax: 225-644-6695
www.elephantlifting.com