

Electric trolley

lacktriangle3-phase (0.5ton \cdot 1ton \cdot 2ton \cdot 3ton \cdot 5ton)

- Gear side plate set
- ⑤ Hex bolt
- 6 Hex nut
- Spring washer
- ® Snap ring
- Gear wheel set
- 10 Gear wheel
- 11 Ball bearing
- 12 Snapring
- (13) Washer
- © Plain side plate set
- 23 Snap ring
- 2 Plain wheel set
- 25 Plain wheel
- 26 Ball bearing
- ②Snap ring
- ²⁸ Washer
- 32 Suspension shaft
- 33 Key plate
- 34 Cotter pin
- 35 Adjust collar
- 36 Ball bearing
- 37 Flange set
- 38 Flange
- 39 Ball bearing
- 49 Ball bearing
- 41) Hex nut
- Spring washer
- 432rd.gear
- @3rd.gear(For low speed)

- 45 4th.gear(For low speed)
- 465th.gear
- 47 Ball bearing
- 48 Snap ring
- 49 Ball bearing
- **1** Rotor set
- Brake drum set
- Brake spring
- 69 Brake cover set
- Brake cover
- @Ball bearing
- 6 Stay bolt
- @Hex cap nut
- ® Spring washer
- @Collar(For 5th. gear)
- 65 Side cover
- 66 Bolt w/hex.hole
- **®** Eye bolt
- © Cord holder set
- **®**Hex nut
- 1 Spring washer
- @ Electric equipment panel set
- Electric equipment panel
- 14 Electric equipment holder
- ® Socket panel
- [®] Magnetic contactor
- 77 Magnetic contactor
- 78 Transformer
- 796P-terminal block set

- Housing socket set (pushbutton side)
- Switch case set
- ® Rubber band
- 66 Screw W/cross hole
- ® Warning label
- Push button hanger set
- 89 Hex nut
- Spring washer
- 93 Name plate
- Coupling cable set for control
- Coupling cable set for power
- Power cord set
- Connector
- 100 2nd gear
- ® Washer
- (®) 3rd gear(For low speed)
- (M) Gear case
- ® Bolt W/hex.hole
- **®** Spring washer
- @ Packing