


Plain Trolley, P type Spare Parts List

Catalog No.		Parts	Parts Name	Q' ty	Remarks
Set No.	Indvdl No.	No.		1 unit	
	4	P-046	Bracket	2	
	5	P-021	Hex. Bolt (Short)	4	for Bracket
	25	P-018	Hex. Bolt (Long)	4	for Key Plate
	6	P-047	Hex. Nut	8	
	7	P-048	Spring Washer	8	
	8	P-034	Snap Ring (Small)	4	
	13	P-035	Wheel Pin Washer	4	
21		P-031	Plain Side Plate Ass'y.	2S	w/Wheel pin
	37	P-926	Name Plate	1	
29		P-037	Plain Wheel Ass'y.	4S	w/Bearing & Snap ring(L)
	30	P-038	Plain Wheel	4	
	11	P-039	Ball Bearing	4	
	12	P-040	Snap Ring (Large)	4	
38		P-060	Suspension Shaft Ass'y.	1S	w/Split Pin
	39	P-061	Suspension Shaft	1	
	41	P-065	Split Pin	1	
	42	P-062	Adjustment Collar		
	43	P-017	Key Plate	2	
	49	P-191	Connector	1	3t, 5t is not Direct type.
	50	P-192	Connector(for Direct)	1	



Geared Trolley, G type Spare Parts List

Catalog No.		Parts No.	Parts Name	Q'ty / 1 unit	Remarks
Set No.	Indvdl No.				
1		G-001	Gear Side Plate Ass'y.	1S	w/Wheel pin & Chain Guide
	4	G-016	Bracket	2	
	5	G-021	Hex. Bolt (Short)	4	for Bracket
	25	G-018	Hex. Bolt (Long)	4	for Key Plate
	6	G-019	Hex. Nut	8	
	7	G-020	Spring Washer	8	
	8	G-004	Snap Ring (Small)	4	
9		G-007	Gear Wheel Ass'y.	2S	w/Bearing & Snap ring(L)
	10	G-008	Gear Wheel	2	
	11	G-009	Ball Bearing	2	
	12	G-010	Snap Ring (Large)	2	
	13	G-005	Wheel Pin Washer	4	
21		G-031	Plain Side Plate Ass'y.	1S	w/Wheel pin
	37	G-926	Name Plate	1	
29		G-037	Plain Wheel Ass'y.	2S	w/Bearing & Snap ring(L)
	30	G-038	Plain Wheel	2	
	11	G-039	Ball Bearing	2	
	12	G-040	Snap Ring (Large)	2	
38		G-060	Suspension Shaft Ass'y.	1S	w/Split Pin
	39	G-061	Suspension Shaft	1	
	41	G-065	Split Pin	1	
	42	G-062	Adjustment Collar	4	
	43	G-017	Key Plate	2	
	44	G-300	Pinion Gear	1	
	45	G-308	Castle Nut	1	
	46	G-312	Split Pin	1	
	47	G-501	Hand Chain Wheel	1	
	48	G-508	Check Washer	1	
	49	G-191	Connector	1	3t,5t is not Direct type.
	50	G-192	Connector(for Direct)	1	